

***Useful tips concerning the rubber band that comes with your RETICLE-TRU™***

If you eventually need to replace the rubber bands that were originally supplied with your Reticle-Tru Alignment Device, the very same rubber bands may be purchased directly from ULINE, telephone # 1-800 295 5510.

The model number is: S - 17255; the size of the band is # 57; and, L x W is; 1  $\frac{3}{4}$  x  $\frac{1}{4}$  inches.

When stretching the rubber band onto the device, I recommend the following: begin by stretching the band across the top of the v-shaped ocular seat—keeping the band tight—so that the remainder of the band that is somewhat less taut will ultimately end up on the bottom side of the device. You can test just how tight the band is by plucking the rubber band—like a harp string—and listening for the sound. If the pitch is higher, the band is good and tight. When the band is tight, it will firmly hold the scope ocular and device together—as if they were one unit—while you complete the remaining steps of the scope alignment process.

When putting the ocular bell of your scope onto the ocular seat of the device, start by trying to align the elevation turret as close to the 12 o'clock position as possible—so that this turret is approximately aligned with the top indicator on the device—and then stretch the band over the top of the ocular. This step will greatly assist in preventing the band from “slightly pulling the device either left or right in a rotational manner” as you work to perfectly align the vertical crosswire within the Reticle-Tru window.

When you are finished using the alignment device, remove the rubber band from the tool and place all of the rubber bands supplied with your Reticle-Tru into a plastic sandwich bag, and store them in your refrigerator.